

# Golf Cart Care & Maintenance

## BEFORE every use

- Check for correct tire inflation.
- Inspect for fluid leaks.
- Inspect battery fluid levels and make sure the batteries are not dry.
- Ensure master switch (under the seat) is turned to the “RUN” position.

## AFTER every use

- Apply parking brake
- Ensure stereo and lights are turned off
- Plug in charger
- If vehicle is not going to be used for some time, turn the master switch to the “TOW” position

## MONTHLY

- Top up battery fluid levels using **distilled water** only
  - Make sure that the batteries are fully charged first
  - Remove the caps from each cell at the top of the battery
  - Fill the battery to just below the ring in the cell neck
  - If the battery is dry and not charged, fill with distilled water to cover the plates only, then charge, then top-up
- Check battery connections
  - Remove any corrosion (powdery stuff)
  - Replace any damaged cables - cables should be flexible
  - Tighten the nuts on the cable terminals
- Check the charger
  - Remove any corrosion
  - Replace (or trim back) any cords that are frayed or cracked
  - Tighten the screws

